

# MPC5534EVB

---

Development Board for the Freescale MPC5534

OPTIONS and CONNECTIONS

|   |           |
|---|-----------|
| <b>CAUTIONARY NOTES</b> .....                     | <b>3</b>  |
| <b>TERMINOLOGY</b> .....                          | <b>3</b>  |
| <b>MPC5534EVB GETTING STARTED</b> .....           | <b>4</b>  |
| <b>MPC5534EVB CONFIGURATION</b> .....             | <b>4</b>  |
| CONFIG SWITCH.....                                | 4         |
| SRAM_SEL OPTION.....                              | 4         |
| <b>POWER SUPPLY</b> .....                         | <b>5</b>  |
| ON_OFF SWITCH .....                               | 5         |
| PWR - POWER JACK.....                             | 5         |
| FUUSE – F1 .....                                  | 5         |
| POWER PORT .....                                  | 6         |
| VSTBY SWITCH AND CT9 .....                        | 6         |
| ANALOG SUPPLIES .....                             | 6         |
| <b>USER COMPONENTS</b> .....                      | <b>7</b>  |
| X1 CLOCK OSCILLATOR.....                          | 7         |
| USER LED.....                                     | 7         |
| USER SWITCH.....                                  | 7         |
| USER_DEV .....                                    | 8         |
| SW1 – SW4 PUSH SWITCHES.....                      | 8         |
| RV1 AND RV2 USER POTENTIOMETERS.....              | 8         |
| SPEAKER AND SPKR_VOL.....                         | 8         |
| <b>MPC5534EVB I/O PORTS</b> .....                 | <b>9</b>  |
| COM-1 PORT.....                                   | 9         |
| <i>JP2 Option</i> .....                           | 9         |
| CAN PORT .....                                    | 9         |
| <i>CAN_SEL Option</i> .....                       | 10        |
| LIN_J1 .....                                      | 10        |
| <i>CT10 Option</i> .....                          | 11        |
| <i>JP3 Option</i> .....                           | 11        |
| <i>JP5 Option</i> .....                           | 11        |
| <i>JP6 Option</i> .....                           | 11        |
| <i>JP4 Option</i> .....                           | 11        |
| <i>LIN_PWR Option</i> .....                       | 11        |
| <i>LIN-J1 Connector</i> .....                     | 12        |
| TPU PORT .....                                    | 12        |
| UNI_3 MOTOR CONTROL PORT .....                    | 12        |
| <i>MOTOR_EN Option</i> .....                      | 13        |
| <i>UNI_3 Port</i> .....                           | 13        |
| <i>HALL ENCODER Port</i> .....                    | 13        |
| <i>RUN STOP Switch</i> .....                      | 14        |
| <i>RV4 FAULT Adjust and Fault Indicator</i> ..... | 14        |
| <i>SW3_UP and SW4_Down</i> .....                  | 14        |
| DEVELOPMENT PORTS .....                           | 14        |
| <i>JTAG Port</i> .....                            | 15        |
| <i>NEXUS Port</i> .....                           | 15        |
| <i>ROBUST Nexus Port</i> .....                    | 16        |
| <i>JP1 Option</i> .....                           | 16        |
| <b>MPC5534 I/O HEADER RING</b> .....              | <b>17</b> |
| A1 – AB4 HEADER .....                             | 17        |
| A18 – D5 HEADER.....                              | 17        |
| A19– AB22 HEADER .....                            | 18        |
| W18– AB18 HEADER .....                            | 18        |
| EVB HEADER ERRATA.....                            | 18        |

# Cautionary Notes

- 1) Electrostatic Discharge (ESD) prevention measures should be applied whenever handling this product. ESD damage is not a warranty repair item.
- 2) Axiom Manufacturing reserves the right to make changes without further notice to any products to improve reliability, function or design. Axiom Manufacturing does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey any license under patent rights or the rights of others.
- 3) EMC Information on the MPC5534EVB board:
  - a) This product as shipped from the factory with associated power supplies and cables, has been tested and meets with requirements of CE and the FCC as a **CLASS A** product.
  - b) This product is designed and intended for use as a development platform for hardware or software in an educational or professional laboratory.
  - c) In a domestic environment this product may cause radio interference in which case the user may be required to take adequate prevention measures.
  - d) Attaching additional wiring to this product or modifying the products operation from the factory default as shipped may effect its performance and also cause interference with other apparatus in the immediate vicinity. If such interference is detected, suitable mitigating measures should be taken.

## Terminology

This development board applies option selection jumpers. Terminology for application of the option jumpers is as follows:

Jumper on, in, or installed = jumper is a plastic shunt that fits across 2 pins and the shunt is installed so that the 2 pins are connected with the shunt.

Jumper off, out, or idle = jumper or shunt is installed so that only 1 pin holds the shunt, no 2 pins are connected, or jumper is removed. It is recommended that the jumpers be idled by installing on 1 pin so they will not be lost.

This development board applies hardwired option selections (VRL\_EN and CUTAWAY 1 – 16). These option selections apply a circuit trace between the option pads to complete a default connection. This type connection places an equivalent Jumper Installed type option. The circuit trace between the option pads maybe cut with a razor blade or similar type knife to isolate the default connection provided. Applying the default connection again can be performed by installing the option post pins and shunt jumper, or by applying a wire between the option pads.

# MPC5534EVB Getting Started

The MPC5534EVB is provided in a kit with basic cables, power supply, support CD, and 3<sup>rd</sup> party software demonstration tools if provided. The support CD contains drawings, manuals, data sheets, and Freescale support software. Software development for the MPC5534 is supported by the Nexus debug port interface to a host PC operating a development tool suite for the MPC5500 devices. Several vendors provide tool suites and these must be purchased or licensed separately. Users should be experienced in embedded applications to apply this product.

## MPC5534EVB Configuration


### CONFIG Switch

The CONFIG switch provides reset configuration options for the MPC5534 device. Configuration options are enabled by position 1 of the switch. Switch positions 2 – 6 OFF provide an active low output condition to the respective configuration signal. Switch position ON will provide an active high signal condition.

| POSITION | CONFIGURATION SIGNAL | DESCRIPTION   |
|----------|----------------------|---|
| 6        | WKPCFG               | <b>ON = default</b> , Refer to Freescale MPC5534 Documentation                                    |
| 5        | PLLCFG1              | <b>OFF = default</b> , Refer to Freescale MPC5534 Documentation                                   |
| 4        | PLLCFG0              | <b>ON = default</b> , Refer to Freescale MPC5534 Documentation                                    |
| 3        | BOOTCFG1             | <b>OFF = default</b> , Refer to Freescale MPC5534 Documentation                                   |
| 2        | BOOTCFG0             | <b>ON = default</b> , Refer to Freescale MPC5534 Documentation                                    |
| 1        | CONFIG enable        | <b>OFF= default</b> . ON = enables the RCON configuration to be applied from the switch settings. |

### SRAM\_SEL Option

The MPC5534EVB board provides a 256K x 18 synchronous SRAM (U2) on the 16 bit data bus D0 – D15. SRAM data bits 16 and 17 are not applied. SRAM\_SEL provides selection of the CS0 or CS1 chip selects to access the external SRAM (U2) on the EVB board. Chip select configuration should be set for 0 wait states, 512K byte memory range, WE signals = Write Enable. The SRAM supports 4 word BURST mode access also.



# POWER Supply

This section covers the MPC5534EVB board power supplies and options. The primary power supply is the MC33730 device configured to support the MPC5534 device. The MPC5534 VRC regulator provides the VDD (1.5V) supply in the default configuration (CT1 and CT4 Open, CT2 and CT3 closed). MC33730 1.5V supply may be applied by optional configuration to provide the VDD 1.5V supply (CT1 and CT4 closed, CT2 and CT3 open).

Power supply Reset signals for the 5V, 1.5V and 3.3V supplies are applied to the MPC5534 RESET\* input by the closed S1 – S3 option pads respectfully. The open S0 option pad may apply the RSTKAM\* back-up supply reset signal if closed by the user. Also see the POWER\_PORT connection and MC33730 data sheet for power supply access details.


## ON\_OFF Switch

The ON\_OFF toggle switch provides ignition on and off control to the MC33730 supply. The MC33730 device will enable and disable the main power supplies. With the switch in the ON position, all power indicators should light. Inspect input power connection and source, and fuse F1 if power indication does not occur.

## PWR - Power Jack

The Power Jack provides the default power input to the board. The jack accepts a standard 2.0 ~ 2.1mm center barrel plug connector (positive voltage center) to provide the +VIN supply of +6 to +24 VDC (+12VDC typical).

+Volts, 2mm center



## FUSE – F1

Input power is limited by fuse F1. A 5x20mm type 1A slow-blow type fuse is applied to protect the EVB board for overload conditions.

## POWER Port

Power Port provides access to the main power supplies and MC33730 optional supplies. Note that the +VIN connection provided at pin 1 is not switched by the ON-OFF switch or fused and is directly connected to the Power Jack.

| PIN # |    | SIGNAL DESCRIPTION  |
|-------|----|---|
| 1     | 2  | +V IN= DC input voltage from PWR jack (NO fuse or polarity protection).                               |
| 3     | 4  | +5V = regulated +5V supply from MC33730   |
| 5     | 6  | +3.3V = regulated +3.3V supply from MC33730   |
| 7     | 8  | +1.5V = regulated +1.5V supply from MC33730   |
| 9     | 10 | VDD = MPC5534 VDD supply, 1.5V typically  |
| 11    |    | VREF1 = MC33730 Optional 5V reference supply.   |
|       | 12 | +5VA = MC33730 VREF2 output dedicated to the MPC5534 5V analog supply.                                |
| 13    |    | RST3* = 3.3V power supply reset signal from MC33730 supply.   |
|       | 14 | VSTBY = 1V backup / standby voltage applied to MPC5534 VSTBY input. See VSTBY_SW and CT9 option also. |
| 15    |    | RSTL* = 1.5V power supply reset signal from MC33730 supply.   |
|       | 16 | REGON = control signal to the M33730, see MC33730 user guide.   |
| 17    |    | RSTH* = 5V power supply reset signal from MC33730 supply.   |
|       | 18 | IGN_ON = control signal output from the MC33730, see MC33730 user guide.                              |
| 19    |    | RSTKAM* = Keep Alive / VSTBY / backup power supply reset signal from the MC33730.                     |
|       | 20 | PFD = control signal output from the MC33730, see MC33730 user guide.                                 |
| 21    | 22 | Ground / VSS  |

## VSTBY SWITCH and CT9

The VSTBY SWITCH provides enabling and disabling the VSTBY operation of the MPC5534 internal RAM. Switch in the OFF position disables the VSTBY operation and the VSTBY pin is connected to VSS / Ground. Switch in the ON position applies the +1VDC VKAM standby voltage from the MC33730 supply to the VSTBY pin.

Cut-away option CT9 allows the user to isolate the VSTBY pin of the MPC5554 from the switch. With CT9 open, the user must apply external battery or ground to the VSTBY position on the Power Port connector or I/O header ring.

## ANALOG Supplies

The MPC5554 VDDA supply (+5V default) is provided by the MC33730 VREF2 regulator output. VRH reference supply is provided by VDDA by default with the VRH\_EN option jumper installed. External VRH reference may be applied by removing the VRH\_EN option and applying reference voltage at header ring I/O pin A10. The VRL\_EN closed option pads connect the signal to common VSS supply by default. User may open this option to apply a precision ground to the VRL signal.

The QADC digital supply is provided +5V by option CT8. An optional connection to +3.3V for the QADC is provided by CT7. CT8 must be opened to install CT7 for +3.3V operation. See the MPC5534 user manual for more details on operating the QADC at +3.3V and limitations of the VDDA and VRH supplies.

# USER Components

The EVB board provides an External clock option (X1), 8 LED indicators, an 8 position DIP switch, 4 push switches, a speaker with amplifier, and 2 user potentiometers. These devices are accessed via the USER LED, USER SWITCH, and USER DEV I/O headers. EVB board user may apply the devices to the MPC5534 I/O header signals to evaluate operation or assist in code development.

## X1 CLOCK Oscillator

The X1 socket is provided to install standard 5V compatible CAN type clock oscillators so that alternate clock source or frequencies maybe applied to the MPC5534. User should refer to the MPC5534 device user manual for information on frequency selection and clocking configuration.

X1 clock signal is provided to the MPC5534 by option pad set CT6 being closed by 0 ohm resistor or mod wire application. CUT-AWAY option CT5 must be opened to remove the Y1 crystal from the EXTAL signal or problems may occur with operation. User should review the MPC5534 user guide for proper PLLCFG0 and PLLCFG1 (CONFIG Switch 4 and 5) option settings if an external clock is applied.

## USER LED

User LED connector provides access to the user LED 1 to 8. Connector pins 1 to 8 are organized in a one to one connection to the individual indicators LED 1 to 8. The LED indicators are buffered for minimal drive current requirement (~300ua). Indicators will turn on with a logic high signal level of 2.5 to 5V applied at the respective connector pin.

## USER Switch

User Switch provides access to the 8 position User DIP Switch. Connector pins 1 to 8 organization provide a one to one organization to the individual DIP switch positions 1 to 8. The switch connections are pulled low with 10K ohm resistors when the switch position in the off position. Switch positions placed in the ON position will provide a 3.3V output to the connector.

## USER\_DEV

User DEV provides access to the 4 push switches (SW1 – SW4), Speaker, and 2 user potentiometers (RV1 and RV2).

| PIN # | USER COMPONENT CONNECTION  |
|-------|--|
| 1     | SW1 out, de-bounced CMOS drive 0 or 3.3V, active low.  |
| 2     | SW1 out, de-bounced Open Drain output, active low, 10K ohm pull-up to 3.3V. Suitable for IRQ input signal drive. |
| 3     | SW2 out, active low, 10K ohm pull-up to 3.3V.  |
| 4     | SW3 out, active low, 10K ohm pull-up to 3.3V.  |
| 5     | SW4 out, active low, 10K ohm pull-up to 3.3V.  |
| 6     | SPEAKER amp input. 0 to 5Vpp, volume adjust with SPKR_VOL.   |
| 7     | RV1 center tap, 0 – 5V adjustment  |
| 8     | RV2 center tap, 0 – 5V adjustment  |

### SW1 – SW4 Push Switches

The push switches provide momentary active low input for user applications. SW1 has additional features of being de-bounced for no glitch operation and push-pull output on pin 1 or open drain output on pin 2. Typical user application would be to provide program control or menu selection input.

SW3\_UP and SW4\_Down are also provided for the UNI\_3 Port motor control operation when the MOTOR\_EN option is installed.

### RV1 and RV2 User Potentiometers

The User Potentiometers provide an adjustable linear voltage output from 0 to 5V. The voltage signal may be applied to an MPC5534 analog input port for user application.

### SPEAKER and SPKR\_VOL

The speaker and amplifier provide user applications with a method to generate sound effects from a MPC5534 output. Frequency range of the amplifier input is 300Hz to 10Khz. The SPKR\_VOL potentiometer allows user adjustment of the sound effect volume from the speaker. The amplifier also provides a SHDN input connection pad. This pad maybe connected to a MPC5534 output signal to disable the amplifier with a logic high signal of 3.3V or 5V.



# MPC5534EVB I/O Ports

## COM-1 Port

COM-1 is a standard RS232 type serial port configured for direct connection to a PC COM Port with a straight through type 9 pin serial cable. Option JP2 provides MPC5534 SCI channel 'A' signal connections when installed. Optional RTS and CTS hardware flow control connection pads are provided for the user to apply MPC5534 I/O ports and software to enhance operation.

### *JP2 Option*

The JP2 Option provides MPC5534 RXDA and TXDA signals to the COM1 transceiver connections. This allows the user to apply the provided communication transceiver with the SCI A channel or to apply the associated I/O to other purposes. JP2 position 1 installed enables the TXDA output and position 2 enables the RXDA input on COM-1.

### COM1

|     |     |         |
|-----|-----|---------|
| 1   | 1   | X       |
| TXD | 2 6 | 6       |
| RXD | 3 7 | CTS IN  |
| 4   | 4 8 | RTS OUT |
| GND | 5 9 | 9       |

The **COM-1** port is a Female (socket type) DB9 connector.

**Pins 1, 4, and 6 connected for status null to host.**

**Pins 7 and 8 maybe applied by CTS and RTS pads to MPC5534 I/O.**

RTS signal active output level is logic 0. User should place I/O port applied at logic low (0) to enable the RTS signal and reception of bytes if applied. User should apply a logic high signal under software control inform host or connected RS232 device to STOP transmitting (stop sending incoming bytes).

CTS signal active input level is logic 0. User should apply software to detect a logic high signal or rising edge on applied I/O port and STOP transmitting bytes to the host or connected device to implement hardware flow control. Detection of a logic low input indicates the host is ready to receive bytes and the user may transmit.

DB9 connector pin locations are provided access pads behind the connector on the EVB board. User may isolate the connection pads by cutting the associated circuit trace on the bottom of the board.

## CAN Port

The CAN Port provides 9 pin connector with a TJA1050 CAN transceiver interface to the MPC5534 CAN channels. The CAN\_SEL option locations select the CAN channel applied to the transceiver and CAN Port. User may apply more than one MPC5534 CAN channel to the port if the open drain TX output type is applied on the associated CAN channel transmit pins.

## CAN\_SEL Option

The CAN\_SEL option header allows selection of the MPC5534 CAN channels applied to the Power Oak transceiver and CAN Port. If more than one transmit channel is applied, transmit pins must apply the open drain output feature.

| POSITION # | MPC5534 CAN SIGNAL                                  |
|------------|---|
| 1          | CNTX_A, channel A TX out ( <b>DEFAULT enabled</b> ) |
| 2          | CNRX_A, channel A RX in ( <b>DEFAULT enabled</b> )  |
| 3          | CNTX_B, channel B TX out (N/A with MPC5534)         |
| 4          | CNRX_B, channel B RX in (N/A with MPC5534)          |
| 5          | CNTX_C, channel C TX out                            |
| 6          | CNRX_C, channel C RX in                             |

Following is the DB9S connection reference.

### CAN\_PORT

|        |            |        |
|--------|------------|--------|
| 1      | <b>1</b>   | X      |
| CAN_LO | <b>2 6</b> | GND    |
| GND    | <b>3 7</b> | CAN_HI |
| 4      | <b>4 8</b> | 8      |
| 5      | <b>5 9</b> | 9      |


**CAN** port has a Female (socket type) DB9 connector.

**CAN\_HI and CAN\_LO signals are terminated together with 120 ohms (R68).**

DB9 connector pin locations are provided access pads behind the connector on the EVB board for additional user application.

## LIN\_J1

The LIN\_J1 port provides a Master Mode LIN network connection. The MPC5534 device provides a LIN Master type node on the LIN Network. A LIN physical layer transceiver U7 (MC33661, or similar) is provided between the MPC5534 device and the LIN network connector. Refer to the MC33661 data sheet for complete details of transceiver operation. The following diagram represents the LIN connection:



The LIN interface provides optional features of slew rate control, network supply, and wake up option. See the JP3, JP4, JP5, JP6, LIN\_PWR and CT10 options following.

## CT10 Option

MPC5534 I/O signal GPIO203 provides LIN transceiver U7 enable control (EN pin). Software control of the EN pin allows the user to set the slew rate control of the transceiver. User applications should configure the GPIO203 pin for output to operate the LIN transceiver. If GPIO203 is needed for other purposes, the CT10 option maybe cut to isolate the signal from the LIN transceiver and JP3 installed to provide an enable to the transceiver. Refer to the MC33361 data sheet for further details of operation.

## JP3 Option

Installation of JP3 applies a pull-up resistor on the LIN transceiver enable pin. MPC5534 GPIO203 may still control the transceiver enable operation when JP3 is installed.

## JP5 Option


JP5 selects the MPC5534 SCI RXDB signal input to be from the LIN transceiver. For LIN operation JP5 must be installed.

## JP6 Option

JP6 is wired closed by default and not populated. JP6 provides the MPC5534 TXDB signal to the LIN transceiver. User may cut the JP6 wire trace to isolate the TXDB signal.

## JP4 Option

LIN-J1 connector pin 2 may be configured for different network requirements by JP4. JP4 open will disconnect LIN-J1 pin 2 from the EVB board.




## LIN\_PWR Option

Installation of the LIN\_PWR option applies MPC5534EVB +V input voltage (12V typical) for LIN network power to LIN-J1 pin 3. This connection allows the EVB board to operate as a LIN master node to power remote LIN slave nodes. User should use caution to not overload the F1 fuse and verify only one source is applied on the network.

## LIN-J1 Connector

The LIN-J1 network connector provides a standard pin configuration with a network option position on pin 2.

**Front view** (looking into connector from outside of board edge)



Mating connector = Molex 39-01-2040 with 39-00-0039 pins.

## TPU Port

The TPU\_PORT provides an organized I/O port for the MPC5534 eTPU\_A signals.

| MPC5534 Signal | TPU Port |    | MPC5534 Signal |
|----------------|----------|----|----------------|
| +3.3V          | 1        | 2  | +5V            |
| eTPU_A16       | 3        | 4  | x              |
| eTPU_A17       | 5        | 6  | x              |
| eTPU_A18       | 7        | 8  | eTPU_A0        |
| eTPU_A19       | 9        | 10 | eTPU_A1        |
| eTPU_A20       | 11       | 12 | eTPU_A2        |
| eTPU_A21       | 13       | 14 | eTPU_A3        |
| eTPU_A22       | 15       | 16 | eTPU_A4        |
| eTPU_A23       | 17       | 18 | eTPU_A5        |
| eTPU_A24       | 19       | 20 | eTPU_A6        |
| eTPU_A25       | 21       | 22 | eTPU_A7        |
| eTPU_A26       | 23       | 24 | eTPU_A8        |
| eTPU_A27       | 25       | 26 | eTPU_A9        |
| eTPU_A28       | 27       | 28 | eTPU_A10       |
| eTPU_A29       | 29       | 30 | eTPU_A11       |
| eTPU_A30       | 31       | 32 | eTPU_A12       |
| eTPU_A31       | 33       | 34 | eTPU_A13       |
| GND            | 35       | 36 | eTPU_A14       |
| TCRCLK_A       | 37       | 38 | eTPU_A15       |
| GND            | 39       | 40 | GND            |

## UNI\_3 Motor Control Port

The UNI\_3 Motor Control Port is provided for easy application of the Freescale UNI\_3 Motor control application boards and motors. Many of the MPC5534 I/O signals are applied for the UNI\_3 motor control application so the user should review I/O application carefully. UNI\_3 port operation is enabled by the MOTOR\_EN option jumper installation.

## MOTOR\_EN Option

This option controls the connection of the MPC5534 I/O ports to the UNI\_3 and HALL\_ENCODER motor control ports. When installed, signal buffers U13 and U15 are enabled to apply MPC5534 I/O for motor control.

### UNI\_3 Port

The UNI\_3 port is the primary motor control I/O port for application of the UNI\_3 motor control development boards. Following are the signal assignments:

| MPC5534 Signal | UNI_3 Signal | UNI_3 Port |    | UNI_3 Signal    | MPC5534 Signal |
|----------------|--------------|------------|----|-----------------|----------------|
| eTPU_A8        | PWM_AT       | 1          | 2  | Common 4,6,8,10 | x              |
| eTPU_A9        | PWM_AB       | 3          | 4  | Common 2,6,8,10 | x              |
| eTPU_A10       | PWM_BT       | 5          | 6  | Common 2,4,8,10 | x              |
| eTPU_A11       | PWM_BB       | 7          | 8  | Common 2,4,6,10 | x              |
| eTPU_A12       | PWM_CT       | 9          | 10 | Common 2,4,6,8  | x              |
| eTPU_A13       | PWM_CB       | 11         | 12 | GROUND          | VSS / GROUND   |
| VSS / GROUND   | GROUND       | 13         | 14 | x               |                |
|                | x            | 15         | 16 | x               |                |
| VSSA           | ANALOG GND   | 17         | 18 | ANALOG GND      | VSSA           |
|                | x            | 19         | 20 | x               |                |
| AN16           | VS_DCB       | 21         | 22 | IS_DCB          | AN17           |
| AN18           | IS_A         | 23         | 24 | ISB             | AN19           |
| AN20           | IS_C         | 25         | 26 | x               |                |
|                | x            | 27         | 28 | x               |                |
| eTPU_A15       | BRAKE        | 29         | 30 | x               |                |
|                | x            | 31         | 32 | x               |                |
|                | x            | 33         | 34 | ZX_A            | eTPU_A5        |
| eTPU_A6        | ZX_B         | 35         | 36 | ZX_C            | eTPU_A7        |
|                | x            | 37         | 38 | BEMF_A          | AN21           |
| AN22           | BEMF_B       | 39         | 40 | BEMF_C          | AN23           |

### HALL\_ENCODER Port

The Hall encoder port is provided for motor position feedback signals from the UNI\_3 motor application development boards.

| HALL Port | HALL Signal | MPC5534 Signal  |
|-----------|-------------|---|
| 1         | +5V         | +5V / VDDH  |
| 2         | GROUND      | VSS / GROUND  |
| 3         | H_1         | eTPU_A1   |
| 4         | H_2         | eTPU_A2   |
| 5         | H_3         | eTPU_A3   |
| 6         | H_4         | eTPU_A4   |
| x         | H_CLK       | TCRCLK_A, H_CLK is derived by logic from the H_1 – 4 signals. |

## *RUN STOP Switch*

The RUN STOP switch is connected to the MPC5534 EMIOS11 signal pin. The switch provides a motor run or stop condition input for the motor control application.

## *RV4 FAULT Adjust and Fault Indicator*

RV4 Fault Adjustment is provided to set the applied motor over-current fault condition. The IS\_DCB current sense input from the UNI\_3 port is compared by U16 with the RV4 setting to determine if an over-current condition exists. If the IS\_DCB input signal is greater than the RV4 setting, the Fault condition becomes active. The FAULT indicator will light and an active low Fault signal will be provided to MPC5534 EMIOS10 signal pin.

## *SW3\_UP and SW4\_Down*

User switches SW3 and SW4 provide the motor speed UP and DOWN input signals when the MOTOR\_EN option is installed. Both switches are active low. SW3\_UP signal is provided to the MPC5534 EMIOS8 signal pin. SW4\_DOWN signal is provided to the MPC5534 EMIOS9 signal pin.

## **DEVELOPMENT PORTS**

The MPC5534EVB board provides 1 JTAG and 2 NEXUS type development ports. Only one of the development ports should be applied due to common signals used on the ports. The development port input and power signals are buffered by a CBTLV3861 device. This buffer provides a bi-directional 5 ohms series resistance on the input signals when powered on. The buffer also provides signal isolation when powered off.

The EVB board applies 100ohm terminations (R89 and R90) on the CLKOUT signal to the Nexus ports. This termination is not recommended for other designs. The Nexus port should be placed as close as possible to the MPC5534 for best solution.

**NOTE: Proper power sequencing must be performed when a development port is applied (cable connected). Development port application power sequence:**

- 1) MPC5534EVB board ON-OFF switch is OFF and no power is applied to the PWR connector.
- 2) Connect development port cable to the desired MPC5534EVB board development port.
- 3) Apply power to the MPC5534EVB board PWR connector and turn ON-OFF switch ON.
- 4) If power is removed or the ON-OFF switch is turned off, remove development cable from board connector and re-apply from step 1 of this procedure.

## JTAG Port

The JTAG port provides a Freescale standard JTAG connection to the MPC5534. The connector is a standard 2x7, .1 inch pin space keyed pin header. Example compatible cables include the OCDEMON™ NP-JTAG ONCE “Wiggler” and the P&E Microcomputer Systems CABPPCNEXUS. Host software must be applied to operate the cables.

### JTAG Port

| Signal   | Pin # | Pin # | Signal  |
|----------|-------|-------|---------|
| B_TDI    | 1     | 2     | GND     |
| TDO      | 3     | 4     | GND     |
| B-TCK    | 5     | 6     | GND     |
| B_EVTI*  | 7     | 8     | JTG8 TP |
| B-RESET* | 9     | 10    | B_TMS   |
| B_+3.3V  | 11    | 12    | GND     |
| B_RDY*   | 13    | 14    | B_JCOMP |

#### Notes:

- 1) B\_... signals are buffered.
- 2) JTG8 TP signal is not connected to the MPC5534 and provides a Test Pad on the board.
- 3) Signals followed by a “\*” symbol are active logic low.
- 4) Pin 7 or the B\_EVTI\* signal may not be supported by all development cables. Option CT11 cut will isolate this signal if not supported by the development cable and issues are present.

## NEXUS Port

The NEXUS port provides a more powerful and higher speed development port for high end tools. The port connector is an AMP 38 pin Mictor style, part number #767053-1.

### NEXUS Port

| Signal            | Pin # | Pin # | Signal  |
|-------------------|-------|-------|---------|
| NXS1 TP           | 1     | 2     | NXS2 TP |
| NXS3 TP           | 3     | 4     | NXS4 TP |
| MDO9              | 5     | 6     | CLKOUT  |
| BOOTCFG1          | 7     | 8     | MDO8    |
| B_RESET*          | 9     | 10    | B_EVTI* |
| TDO               | 11    | 12    | B_+3.3V |
| MDO10             | 13    | 14    | B_RDY*  |
| B_TCK             | 15    | 16    | MDO7    |
| B_TMS             | 17    | 18    | MDO6    |
| B_TDI             | 19    | 20    | MDO5    |
| B_JCOMP           | 21    | 22    | MDO4    |
| MDO11             | 23    | 24    | MDO3    |
| ERSTOUT*          | 25    | 26    | MDO2    |
| NXS27 TP          | 27    | 28    | MDO1    |
| NXS29 TP (Note 3) | 29    | 30    | MDO0    |
| +V                | 31    | 32    | EVTO*   |
| +V                | 33    | 34    | MCKO    |
| NXS35 TP (Note 3) | 35    | 36    | MSEO1*  |
| B_VSTBY           | 37    | 38    | MSEO0*  |

**Notes:**

- 1) B\_... signals are buffered.
- 2) NXSxx TP signals are not connected to the MPC5534 and provide a Test Pad on the board.
- 3) NXSxx signal TP is also connected to the ROBUST Nexus connector.
- 4) Signals followed by a "\*" symbol are active logic low.

*ROBUST Nexus Port*

The ROBUST port connector location is provided for user expansion. This port provides the ROBUST Nexus 51 pin location that applies the GLENAIR MR7580-51P2BNU connector.

**ROBUST Port**


| Pin # | Signal   | Pin # | Signal   | Pin # | Signal    |
|-------|----------|-------|----------|-------|-----------|
| 1     | +V       | 19    | MDO0     | 36    | GND       |
| 2     | +V       | 20    | GND      | 37    | MDO4      |
| 3     | B_VSTBY1 | 21    | MCKO     | 38    | GND       |
| 4     | NXS35 TP | 22    | GND      | 39    | MDO5      |
| 5     | TDO      | 23    | EVTO*    | 40    | GND       |
| 6     | B_RDY*   | 24    | GND      | 41    | MDO6      |
| 7     | B_RESET* | 25    | MSEO0*   | 42    | GND       |
| 8     | B_+3.3V  | 26    | MDO9     | 43    | MDO7      |
| 9     | B_EVTI*  | 27    | MDO1     | 44    | GND       |
| 10    | GND      | 28    | GND      | 45    | MDO8      |
| 11    | B_JCOMP  | 29    | MDO2     | 46    | GND       |
| 12    | GND      | 30    | GND      | 47    | MDO10     |
| 13    | B_TMS    | 31    | MDO3     | 48    | GND       |
| 14    | GND      | 32    | GND      | 49    | MDO11     |
| 15    | B_TDI    | 33    | NXS29 TP | 50    | GND       |
| 16    | GND      | 34    | GND      | 51    | JP1 pin 2 |
| 17    | B_TCK    | 35    | MSEO1*   |       |           |
| 18    | GND      |       |          |       |           |

**Notes:**

- 1) NXS29 and NXS35 signals are also connected to the NEXUS connector.
- 2) Signals followed by a "\*" symbol are active logic low.

*JP1 Option*

JP1 provides signal selection for the Robust Nexus connector pin 51. Position 1-2 provides the BOOTCFG1 signal and position 2-3 provides the ERSTOUT\* signal.





# MPC5534 I/O HEADER RING

MPC5534 I/O signals are provided by the I/O header ring. The header ring consists of .1 inch grid pins organized in 4 rows for each side of the MPC5534 device. Each row reflects the corresponding location of the MPC5534 device BGA package ball ring. Signals indicated are the EVB board primary function.

## A1 – AB4 HEADER

| PIN | SIGNAL   | PIN | SIGNAL   | PIN | SIGNAL   | PIN | SIGNAL   |
|-----|----------|-----|----------|-----|----------|-----|----------|
| A1  | GND      | A2  | VDD      | A3  | VSTBY    | A4  | AN37     |
| B1  | 3.3V     | B2  | GND      | B3  | VDD      | B4  | AN36     |
| C1  | eTPU_A30 | C2  | eTPU_A31 | C3  | GND      | C4  | VDD      |
| D1  | eTPU_A28 | D2  | eTPU_A29 | D3  | eTPU_A26 | D4  | GND      |
| E1  | eTPU_A24 | E2  | eTPU_A27 | E3  | eTPU_A25 | E4  | eTPU_A21 |
| F1  | eTPU_A23 | F2  | eTPU_A22 | F3  | eTPU_A17 | F4  | eTPU_A18 |
| G1  | eTPU_A20 | G2  | eTPU_A19 | G3  | eTPU_A14 | G4  | eTPU_A13 |
| H1  | eTPU_A16 | H2  | eTPU_A15 | H3  | eTPU_A10 | H4  | 5V       |
| J1  | eTPU_A12 | J2  | eTPU_A11 | J3  | eTPU_A6  | J4  | eTPU_A9  |
| K1  | eTPU_A8  | K2  | eTPU_A7  | K3  | eTPU_A2  | K4  | eTPU_A5  |
| L1  | eTPU_A4  | L2  | eTPU_A3  | L3  | eTPU_A0  | L4  | eTPU_A1  |
| M1  | BDIP*    | M2  | TCRCLK_A | M3  | CS1*     | M4  | CS0*     |
| N1  | CS3*     | N2  | CS2*     | N3  | WE1*     | N4  | WE0*     |
| P1  | A16      | P2  | A17      | P3  | RD_WR    | P4  | 3.3V     |
| R1  | A18      | R2  | A19      | R3  | 3.3V     | R4  | TA*      |
| T1  | A20      | T2  | A21      | T3  | A12      | T4  | TS*      |
| U1  | A22      | U2  | A23      | U3  | A13      | U4  | A14      |
| V1  | A24      | V2  | A25      | V3  | A15      | V4  | A31      |
| W1  | A26      | W2  | 3.3V     | W3  | A30      | W4  | GND      |
| Y1  | A28      | Y2  | A27      | Y3  | GND      | Y4  | VDD      |
| AA1 | A29      | AA2 | GND      | AA3 | VDD      | AA4 | 3.3V     |
| AB1 | GND      | AB2 | VDD      | AB3 | 3.3V     | AB4 | D0       |

< See Errata below

## A18 – D5 HEADER

| PIN | SIGNAL | PIN | SIGNAL | PIN | SIGNAL | PIN | SIGNAL |
|-----|--------|-----|--------|-----|--------|-----|--------|
| A18 | MDO10  | B18 | MDO7   | C18 | MDO2   | D18 | MDO3   |
| A17 | MDO11  | B17 | MDO9   | C17 | MDO5   | D17 | MDO6   |
| A16 | AN12   | B16 | AN13   | C16 | AN14   | D16 | AN15   |
| A15 | VSSA   | B15 | VSSA   | C15 | VDDA0  | D15 | VDDEH9 |
| A14 | AN35   | B14 | AN32   | C14 | AN33   | D14 | AN34   |
| A13 | AN28   | B13 | AN31   | C13 | AN30   | D13 | AN29   |
| A12 | AN27   | B12 | AN26   | C12 | AN25   | D12 | AN24   |
| A11 | VRL    | B11 | AN23   | C11 | AN22   | D11 | AN6    |
| A10 | VRH    | B10 | x      | C10 | AN7    | D10 | AN2    |
| A9  | AN5    | B9  | AN4    | C9  | AN3    | D9  | AN18   |
| A8  | AN1    | B8  | AN0    | C8  | AN21   | D8  | AN10   |
| A7  | VSSA   | B7  | AN16   | C7  | AN20   | D7  | AN9    |
| A6  | VDDA1  | B6  | AN19   | C6  | AN17   | D6  | AN38   |
| A5  | AN11   | B5  | AN39   | C5  | AN8    | D5  | VDD    |

## A19– AB22 HEADER

| PIN  | SIGNAL  | PIN  | SIGNAL     | PIN  | SIGNAL   | PIN  | SIGNAL    |
|------|---------|------|------------|------|----------|------|-----------|
| A19  | MDO8    | A20  | VDD        | A21  | 3.3V     | A22  | GND       |
| B19  | MDO4    | B20  | MDO0       | B21  | GND      | B22  | 3.3V      |
| C19  | MDO1    | C20  | GND        | C21  | 3.3V     | C22  | VDD       |
| D19  | GND     | D20  | 3.3V       | D21  | TCK      | D22  | TDI       |
| E19  | 3.3V    | E20  | TMS        | E21  | TDO      | E22  | TEST*     |
| F19  | 3.3v    | F20  | JCOMP      | F21  | MSEO0*   | F22  | EVTO*     |
| G19  | RDY*    | G20  | MCKO       | G21  | EVTI*    | G22  | MSEO1*    |
| H19  | 5V      | H20  | GPIO203    | H21  | GPIO204  | H22  | SIN_B     |
| J19  | SOUT_B  | J20  | PCS_B3     | J21  | PCS_B0   | J22  | PCS_B1    |
| K19  | PCS_A3  | K20  | PCS_B4     | K21  | SCK_B    | K22  | PCS_B2    |
| L19  | PCS_B5  | L20  | SOUT_A     | L21  | SIN_A    | L22  | SCK_A     |
| M19  | PCS_A1  | M20  | PCS_A0     | M21  | PCS_A2   | M22  | 5V        |
| N19  | PCS_A4  | N20  | TXDA       | N21  | PCS_A5   | N22  | 3.3V      |
| P19  | CNTX_C  | P20  | RXDA       | P21  | RSTOUT*  | P22  | RSTCFG*   |
| R19  | WKPCFG  | R20  | CNRX_C     | R21  | TXDB     | R22  | RESET*    |
| T19  | RXDB    | T20  | BOOTCFG1   | T21  | GND      | T22  | VSSSYN    |
| U19  | 5V      | U20  | PLLCFG1    | U21  | BOOTCFG0 | U22  | x (EXTAL) |
| V19  | VDD     | V20  | x (VRCCTL) | V21  | PLLCFG0  | V22  | x (XTAL)  |
| W19  | GND     | W20  | VDD        | W21  | VRC33    | W22  | VDDSYN    |
| Y19  | x (NC2) | Y20  | GND        | Y21  | VDD      | Y22  | 3.3V      |
| AA19 | 3.3V    | AA20 | CLKOUT     | AA21 | GND      | AA22 | VDD       |
| AB19 | CANRX_B | AB20 | 3.3V       | AB21 | ENGCLK   | AB22 | GND       |

## W18– AB18 HEADER

| PIN | SIGNAL  | PIN | SIGNAL  | PIN  | SIGNAL  | PIN  | SIGNAL  |
|-----|---------|-----|---------|------|---------|------|---------|
| W18 | x (NC1) | Y18 | 3.3V    | AA18 | CNRX_A  | AB18 | CANTX_B |
| W17 | 3.3V    | Y17 | CNTX_A  | AA17 | EMIOS23 | AB17 | EMIOS20 |
| W16 | EMIOS21 | Y16 | EMIOS22 | AA16 | EMIOS19 | AB16 | EMIOS18 |
| W15 | EMIOS12 | Y15 | EMIOS17 | AA15 | EMIOS16 | AB15 | EMIOS14 |
| W14 | 5V      | Y14 | EMIOS15 | AA14 | EMIOS13 | AB14 | EMIOS11 |
| W13 | EMIOS8  | Y13 | EMIOS10 | AA13 | EMIOS9  | AB13 | EMIOS7  |
| W12 | EMIOS2  | Y12 | EMIOS6  | AA12 | EMIOS5  | AB12 | EMIOS4  |
| W11 | D14     | Y11 | D15     | AA11 | EMIOS3  | AB11 | EMOS1   |
| W10 | D12     | Y10 | D13     | AA10 | 3.3V    | AB10 | EMOS0   |
| W9  | D11     | Y9  | GPIO207 | AA9  | D7      | AB9  | OE*     |
| W8  | 3.3V    | Y8  | D10     | AA8  | D5      | AB8  | D6      |
| W7  | 3.3V    | Y7  | D9      | AA7  | GPIO206 | AA7  | D4      |
| W6  | 3.3V    | Y6  | D8      | AA6  | 3.3V    | AA6  | D3      |
| W5  | VDD     | Y5  | 3.3V    | AA5  | D1      | AA5  | D2      |

Note: Indicated as W18 / AB6 on EVB board.

## EVB HEADER ERRATA

EVB revisions A, B, and C incorrectly connect I/O header pins F3 and F4. MPC5534 pin F3 signal eTPU\_A17 appears on header pin F4. MPC5534 pin F4 signal eTPU\_A18 appears on header pin F3. This error is corrected on revision D and later.