

MPC567XADAT516 QUICK START GUIDE

Introduction and Default Settings

The MPC567XADAT516 daughter card (DC) is designed to mount directly to the MPC567XEVBMB (EVBMB) base board. To mount the MPC567XADAT516, the user must first remove the MPC567XADAT416 DC. To remove the installed DC, apply pressure along the DC edge overhanging the FXMB. After the first stack connector disengages, separate the DC from the EVBMB

CAUTION

Do not rotate the daughter card excessively during removal. Damage to the board stack connectors may occur otherwise

To install the MPC567XADAT516 DC, align the 4 stack connectors and press down firmly until the connectors “snap-in”. The board stack connectors are designed with positive detent.

The EVBMB board stack connectors are oriented such that the DC will mount in the correct orientation

Please contact Freescale Semiconductors for further assistance. Refer to the Technical Information Card (TIC) included in the kit for contact information. Assistance may also be found by contacting Axiom Manufacturing at support@axman.com.

